

**ROTAX**

AIRCRAFT ENGINES

# SERVICE BULLETIN

## REVISION OF OPERATOR'S MANUAL FOR ROTAX® ENGINE TYPE 912 AND 914 (SERIES

SB-912-038UL

SB-914-024UL

### **MANDATORY**

#### Repeating symbols:

Please, pay attention to the following symbols throughout this document emphasizing particular information.

- ▲ **WARNING:** Identifies an instruction, which if not followed, may cause serious injury or even death.
- **CAUTION:** Denotes an instruction which if not followed, may severely damage the engine or could lead to suspension of warranty.
- ◆ **NOTE:** Information useful for better handling.

#### 1) Planning information

##### 1.1) Engines affected

All versions of the engine type:

- 912 UL (Series)
- 912 ULS (Series)
- 912 ULSFR (Series)
- 914 UL (Series)

For complete instructions and compliance to this service bulletin refer to Service Bulletin-SB-912-038, SB-914-024, latest edition section 1.2 onward.

- ◆ **NOTE:** Section 1.6) Approval is not required for engines of the type UL (series).  
Section 3) Accomplishment, in addition: persons with adequate type-specific training.

**AUFGEHOBEN (ersetzt durch Betriebsanhandbuch 912 und 914 Serie letztgültige Ausgabe)**  
**CANCELLED (superseded by Operator's Manual 912 and 914 Series latest edition)**

d03130

NOVEMBER 2002  
Initial issue

Copyright - ROTAX®

SB-912-038UL  
SB-914-024UL  
page 1 of 1