



# SERVICE BULLETIN

## CHECKING OF THE CRANKCASE

### ON ROTAX® ENGINE TYPE 912 AND 914 (SERIES)

#### SB-912-029UL R3

#### SB-914-018UL R3

## MANDATORY

### Repeating symbols:

Please, pay attention to the following symbols throughout this document emphasizing particular information.

- ▲ **WARNING:** Identifies an instruction, which if not followed, may cause serious injury or even death.
- **CAUTION:** Denotes an instruction which if not followed, may severely damage the engine or could lead to suspension of warranty.
- ◆ **NOTE:** Information useful for better handling.

### 1) Planning information

#### 1.1) Engines affected

All versions of the engine type:

- 912 UL to S/N 4,407.859
- 912 ULS to S/N 5,646.559
- 912 ULSFR to S/N 4,430.310
- 914 UL to S/N 4,419.315
- V912 pre-production
- V914 pre-production

All crankcase assy. supplied as replacement part with the following serial numbers:  
up to and including S/N 27811

For complete instructions and compliance to this service bulletin refer to Service Bulletin SB-912-029 and SB-914-018, latest edition section 1.2 onward.

- ◆ **NOTE:** Section 1.6) Approval: Is not required for engines of the type UL (series).  
Section 3) Accomplishment: In addition: persons with adequate type-specific training.

d/02392